IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS

WARNING: Risk of fire and electrical shock. This product is to be installed by a qualified electrician only.

CAUTION: When using electrical equipment, basic safety precautions should always be followed including the following: Read all instructions carefully before installation and save

for future use. Make sure installation and all connections are in accordance with National Electrical Code and any local regulations. To avoid possible electrical shock, be sure that power supply is turned off before installing or servicing this fixture. Servicing should be performed by qualified service personnel.

These instructions do not claim to cover all details or variations. When additional information is desired, please contact your SPI representative.

INTERIOR WALL SCONCE

NOTES:

- 1. REMOVE (4) KNURL NUTS FROM INSIDE FIXTURE & REMOVE FIXTURE MOUNTING PLATE.
- 2. ATTACH FIXTURE MOUNTING PLATE OVER J-BOX (BY OTHERS) USING HARDWARE (BY OTHERS). AUXILIARY MOUNTING HOLES ARE PROVIDED.
- 3. MAKE NECESSARY ELECTRICAL CONNECTIONS.
- 4. MOUNT FIXTURE ONTO FIXTURE MOUNTING PLATE & SECURE WITH (4) KNURL NUTS.



