## IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS

WARNING: Risk of fire and electrical shock. This product is to be installed by a qualified electrician only.

CAUTION: When using electrical equipment, basic safety precautions should always be followed including the following: Read all instructions carefully before installation and save

for future use. Make sure installation and all connections are in accordance with National Electrical Code and any local regulations. To avoid possible electrical shock, be sure that power supply is turned off before installing or servicing this fixture. Servicing should be performed by qualified service personnel.

These instructions do not claim to cover all details or variations. When additional information is desired, please contact your SPI representative.

MARKER LIGHT DAMP LOCATION FOR BEST FIT J-BOX **J-BOX 2 1/8" DEEP TO BE RECESSED .060-.125"** IS NEEDED FOR FIXTURE FROM WALL AND CAN NOT PROTRUDE FROM WALL. #8-32 FLAT HEAD SCREW(S) J-BOX BALL STUD(S) (BY OTHERS) FACE PLATE ASSEMBLY WALL **INSTALLATION STEPS:** 1. MAKE NECESSARY WIRED CONNECTIONS PER LOCAL CODE\*. **MUST NOT REMOVE** FIRE PROTECTIVE PAPER 2. PLACE LIGHT FIXTURE INTO JUCTION AND FASTEN WITH

3. SNAP FACE PLATE AGAINST WALL MAKING SURE THAT BALL STUD FASTENERS SNAP INTO BALL STUD RECEIVERS IF FACE PLATE DOES NOT SNAP INTO FIXTURE APPLY ADDITIONAL WASHERS BEHIND BALL STUDS.

\*NOTE THAT INCOMMING POWER MUST COME IN THROUGH SIDE OF J-BOX AND NOT THROUGH THE BACK.

03/14/2014 IS80198X



#8-32 FLAT HEAD SCREWS.