IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS


WARNING: Risk of fire and electrical shock. This product is to be installed by a qualified electrician only.


CAUTION: When using electrical equipment, basic safety precautions should always be followed including the following: Read all instructions carefully before installation and save

for future use. Make sure installation and all connections are in accordance with National Electrical Code and any local regulations. To avoid possible electrical shock, be sure that power supply is turned off before installing or servicing this fixture. Servicing should be performed by qualified service personnel.


These instructions do not claim to cover all details or variations. When additional information is desired, please contact your SPI representative.

STYK - BRACKET LINEAR MOUNT






START SECTION



COMMON / END SECTION



START / END BRACKET

COMMON BRACKET

- 1. CONTINUOUS ROW ASSEMBLIES WILL CONSIST OF A START, AN END AND POSSIBLY COMMON SECTIONS.
- 2. ALL ASSEMBLIES SHOULD BE ASSEMBLED FROM LEFT TO RIGHT WHEN LOOKING AT THE MOUNTING SURFACE. POWER CORDS WILL EXIT FROM THE RIGHT SIDE OF ALL FIXTURES IN THE CONTINUOUS ROW.
- 3. MOUNT START BRACKET TO THE WALL WITH MALE POST POINTING TO THE RIGHT. LOOSEN SET SCREW IN THE SECTION HUB AND SLIDE OVER THE POST.
- 4. LOOSEN SET SCREW IN OPPOSITE END HUB AND SLIDE THE POST FROM THE COMMON BRACKET INTO THE HUB. MOUNT COMMON BRACKET TO WALL AND TIGHTEN BOTH SET SCREWS TO LOCK IN PLACE. MOUNT LEFT END OF NEXT SECTION TO EXPOSED POST.
- 5. CONTINUE STEP 3 AND 4 UNTILL ALL SECTIONS ARE SECURED, WITH THE END SECTION FINISHING OFF THE RUN 2/11/22 IS77441X