

IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS

WARNING: Risk of fire and electrical shock. This product is to be installed by a qualified electrician only.

CAUTION: When using electrical equipment, basic safety precautions should always be followed including the following: Read all instructions carefully before installation and save

for future use. Make sure installation and all connections are in accordance with National Electrical Code and any local regulations. To avoid possible electrical shock, be sure that the power supply is turned off before installing or servicing this fixture. Servicing should be performed by qualified service personnel.

These instructions do not claim to cover all details or variations. When additional information is desired, please contact your SPI representative.

SURFACE MOUNT EXTERIOR - (SRF)

INSTALLATION:

1. TURN POWER OFF.
2. REMOVE FACE PLATE W/ LIGHT TUBE, SET ASIDE.
3. MOUNT FIXTURE BOX TO WALL (WITH FASTENERS BY OTHERS).
4. MAKE ALL ELECTRICAL CONNECTIONS TO FIXTURE BOX PER CODE.
5. APPLY A CONTINUOUS "GENEROUS " BEAD OF SILICONE AT FIXTURE BOX PERIMETER. NOTE: IF EXTERIOR WALL IS NOT COMPLETELY FLAT, THE GAPS WILL NEED TO BE FILLED IN WITH SILICONE AS NEEDED. LET SILICONE DRY.
6. WIRE FACE PLATE W/ LIGHT TUBE TO POWER SUPPLY.
7. SECURE FACE PLATE TO FIXTURE BOX BY INSTALLING SCREWS.
DO NOT OVER TIGHTEN
8. TURN POWER ON & TEST.

FACE PLATE W/ LIGHT TUBE

SCREW

FIXTURE WALL BOX

WIRES

WALL

TOP VIEW

WALL

SILICONE BEAD

FIXTURE BOX

MOUNTING HOLES

MOUNTING HOLES

4/17/23

IS113835X