

IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS

WARNING: Risk of fire and electrical shock. This product is to be installed by a qualified electrician only.

CAUTION: When using electrical equipment, basic safety precautions should always be followed including the following: Read all instructions carefully before installation and save

for future use. Make sure installation and all connections are in accordance with National Electrical Code and any local regulations. To avoid possible electrical shock, be sure that power supply is turned off before installing or servicing this fixture. Servicing should be performed by qualified service personnel.

These instructions do not claim to cover all details or variations. When additional information is desired, please contact your SPI representative.

REMOTE CLASS II POWER SUPPLY - WIRING INSTRUCTIONS

LED WIRING REQUIREMENTS

>LED CLASS 2 POWER SUPPLY ORDERED SEPARATELY FROM FIXTURE. SEE RECOMMENDED POWER SUPPLY INFORMATION BELOW. CONSULT FACTORY FOR ORDERING INFORMATION.

CAUTION: FIXTURE MUST BE CONNECTED TO A CLASS 2 POWER UNIT. FAILURE TO USE A CLASS 2 POWER UNIT VOIDS WARRANTY AND UL LISTING.

>MULTIPLE FIXTURES MAY BE CONNECTED TO ONE LED POWER SUPPLY TO CREATE A CIRCUIT.

>THE VOLTAGES OF ALL FIXTURES ON THE SAME POWER SUPPLY MUST BE THE SAME OUTPUT VOLTAGE. COMBINED WATTAGE OF FIXTURES MUST NOT EXCEED CAPACITY OF POWER SUPPLY.

>CONSULT FACTORY FOR LED DIMMING, RGB, AND DMX INTERFACE.

>LOW VOLTAGE CIRCUITS ARE LIMITED BY CURRENT CAPACITY AND VOLTAGE DROPS THROUGH CONDUCTORS.

>DETERMINE THE APPROPRIATE CABLE FOLLOWING THE MAXIMUM CABLE LENGTH AS DEFINED ON INDIVIDUAL POWER SUPPLY SPEC SHEETS.

>ALL FIXTURES AND CIRCUIT BRANCHES TO BE WIRED IN PARALLEL.

>INSTALL AND CONNECT LED POWER SUPPLIES IN ACCORDANCE WITH NEC, ARTICLE 725, AND ANY LOCAL REGULATIONS AND CODES.

